



Developed by Cole J, Dhayalan B, Luke T, Nicholas K




Blood Oxygen Monitor

Using MAX30102 sensor,
Grove-LCD-backlight display, and a
PIC24 microcontroller


Purpose




- Health Monitoring: The project aims to provide individuals with a convenient and accessible means of monitoring their vital signs, specifically blood oxygen saturation (SpO2) and heart rate.
- Real-Time Feedback
- Promoting Awareness: With increasing interest in personal health monitoring, this project fosters awareness of vital signs.
- How does it work? The MAX30102 combined two LEDs, a photodetector, Optimized optics, and signal processing to detect SpO2 and HR. The sensor uses photodiodes to measure the light reflected by the blood represented by analog sensors.



Monitor Schematic



Block Diagram/Algorithm



MAX30102 Library

Consists of:

- Configuration.
- Reading in data from the FIFO buffer.
- Processing the data into a readable spo2 and heart rate values.
 - Spo2 algorithm: peak detections in PPG cycle/calculations(Arduino)





Figure 2. Graphical Representation of the FIFO Data Register. It shows IR and Red in SpO₂ Mode.

Register Maps and Descriptions


REGISTER	B7	B6	B5	B4	B3	B2	B1	B0	REG ADDR	POR STATE	R/W
STATUS											
Interrupt Status 1	A_FULL	PPG_RDY	ALC_OVF					PWR_RDY	0x00	0x00	R
Interrupt Status 2							DIE_TEMP_RDY		0x01	0x00	R
Interrupt Enable 1	A_FULL_EN	PPG_RDY_EN	ALC_OVF_EN						0x02	0x00	R/W
Interrupt Enable 2							DIE_TEMP_RDY_EN		0x03	0x00	R/W
FIFO											
FIFO Write Pointer								FIFO_WR_PTR[4:0]	0x04	0x00	R/W
Overflow Counter								OVF_COUNTER[4:0]	0x05	0x00	R/W
FIFO Read Pointer								FIFO_RD_PTR[4:0]	0x06	0x00	R/W
FIFO Data Register								FIFO_DATA[7:0]	0x07	0x00	R/W
CONFIGURATION											
FIFO Configuration		SMP_AVE[2:0]		FIFO_ROLL_OVER_EN			FIFO_A_FULL[3:0]		0x08	0x00	R/W
Mode Configuration	SHDN	RESET					MODE[2:0]		0x09	0x00	R/W
SpO ₂ Configuration	0 (Reserved)	SPO2_ADC_RGE[1:0]		SPO2_SR[2:0]			LED_PW[1:0]		0x0A	0x00	R/W
RESERVED									0x0B	0x00	R/W
LED Pulse Amplitude							LED1_PA[7:0]		0x0C	0x00	R/W
							LED2_PA[7:0]		0x0D	0x00	R/W
RESERVED									0x0E	0x00	R/W
RESERVED									0x0F	0x00	R/W
Multi-LED Mode Control Registers			SLOT2[2:0]				SLOT1[2:0]		0x11	0x00	R/W
			SLOT4[2:0]				SLOT3[2:0]		0x12	0x00	R/W

MAX30102 and the PIC24 Micro


- Uses I2C communication
- Setting up configurations of SP02, FIFO, MODE... etc.
 - Used bitmask to config the sensor
- Uses buffer to store readings from the sensor
 - RED and IR LED buffers
- Algorithm to read data from the FIFO (implemented by the group)
- Utilizes Arduino SP02 Algorithm to process data
- Shortfalls:
 - 4 extra pins not used
 - Choosing perfect configuration
 - Using NACK and ACK correctly
 - Reading Data from FIFO
 - Heart Rate not entirely accurate due to sensor




MAX30102 Algorithms




Reading data algorithm:



Grove - LCD RGB Backlight



- Why the Grove?
 - 16x2 Display
 - RGB backlight – more fun with color right?!
 - I2C → Only 2 pins
- Trials and Tribulations
 - Datasheet – not much help, however lab5 and arduino clutched
 - Delayed Update Time – Interfered with sensor
 - Power Resets – Sticky screen!?
 - Lack of space → Button!



LCD/RGB Library

- #include
 - "xc.h", <string.h>, "rgb_lcd_display.h"
- Functions
 - init_I2C1() – baud rate, enable I2C
 - grovergb_init() – initialize display - datasheet
 - setRGB(r,g,b) – set desired color value 0-255
 - Helper functions: clear, home, display(on/off), blink(on/off), setColorAll/White/Red, setCursor, printChar, printStr

COMMAND	COMMAND CODE									COMMAND CODE	E-CYCLE $f_{osc}=270KHz$
	RS	DB7	DB6	DB5	DB4	DB3	DB2	DB1	DB0		
SCREEN CLEAR	0	0	0	0	0	0	0	0	1	Screen Clear, Set AC to 0 Cursor Reposition	1.53ms
CURSOR RETURN	0	0	0	0	0	0	0	1	*	DDRAM AD=0, Return, Content Changeless	1.53ms
INPUT SET	0	0	0	0	0	0	1	I/D	S	Set moving direction of cursor Appoint if move	39us
DISPLAY SWITCH	0	0	0	0	0	1	D	C	B	Set display on/off,cursor on/off, blink on/off	39us
SHIFT	0	0	0	0	1	S/C	R/L	*	*	Remove cursor and whole display,DDRAM changeless	39us
FUNCTION SET	0	0	0	1	DL	N	F	*	*	Set DL,display line,font	39us
CGRAM AD SET	0	0	1	ACG						Set CGRAM AD, send receive data	39us
DDRAM AD SET	0	1	ADD						Set DDRAM AD, send receive data	39us	
CGRAM/ DDRAM DATA WRITE	1	DATA WRITE							Write data from CGRAM or DDRAM		43us
	I/D=1: Increment Mode; I/D=0: Decrement Mode S=1: Shift S/C=1: Display Shift; S/C=0: Cursor Shift R/L=1: Right Shift; R/L=0: Left Shift DL=1: 8D DL=0: 4D N=1: 2R N=0: 1R F=1: 5x10 Style; F=0: 5x7 Style									DDRAM: Display data RAM CGRAM: Character Generator RAM ACG: CGRAM AD ADD: DDRAM AD & Cursor AD AC: Address counter for DDRAM & CGRAM	E-cycle changing with main frequency. Example: If f_{cp} or $f_{osc}=270KHz$ 40us x 250/270 =37us

Switching via Button

- Simple Button used to switch between displaying Blood Oxygen and Heart Rate
- Initialization: Sets button and Timer 2 interrupts
- Input Capture used to detect button press
- Switch states using bool "displayHeartRate"
- Get function getButtonState for usage in other files



Contributions/ Bigger Brains


Dhayalan - wiring, max30102 library(configurations, I2C, reading algorithms/data processing, integration of all libraries), and testing.


Luke - Button, LCD, Moving Average, documentation, good vibes, ect.

Nicholas - Sensor Configs, PART_ID/Read Alg, I2C comm, documentation.

Cole - LCD text and color functionality/code, documentation, etc.

The majority of our learning came through a much deeper understanding of I2C and how to use other devices with the PIC24.





THANK YOU!

Any Questions?

